



## WALLPAPER INSTRUCTIONS

### STEP 1: SURFACE PREPARATION

To ensure your *anewall* adhesive sticks to the surface, make sure it is completely smooth, clean, and dry. Walls must be smooth before installation. Any type of wall texture, including orange peel texture, will not allow your mural to adhere properly. Give your surface a brief wipe down with a clean, dry cloth.

### STEP 2: PLANNING YOUR LAYOUT

Please lay out all panels before beginning your installation. Revisit our website if you need a reference photo of your design. The panels included in your package are numbered on the back and must be installed in chronological order from left to right in order to achieve the final mural design.

Mark your wall for positioning of Panel 1. For ease of installation, leave a 2" bleed of excess on the left side. To ensure straightness of your mural, use a level to mark the end of Panel 1.

### STEP 3: INSTALL FIRST PANEL

Peel back 2" of the lining and trim. Leave a slight 2" bleed overhang at the top of the first panel to begin installation. This will avoid any gapping due to slanting and uneven walls and ceilings.

Use a plastic scraper or squeegee to smooth out the panel onto the wall. Remove the lining as you go.

MATERIALS NEEDED: Clean dry cloth, measuring tape, level, straight edge ruler, Exacto knife, plastic scraper or squeegee.

If bubbling begins to occur once the panel is installed, poke the bubble with a needle or exacto knife and smooth it out with your scraper or squeegee.

### STEP 4: INSTALL SECOND PANEL

Approximately 1.5" of the second panel will overlap the first panel. Most importantly, the overlap will help you line up the design easily. Peel back the lining at the top and remove as you work your way down. Squeegeeing and smoothing as you go. Continue for the rest of the panels and trim the excess wallpaper once finished.

### \*\*OPTIONAL STEP 5: CUTTING THE SEAM

If the seams between the panels are noticeable, take a straight edge ruler and an exacto knife to slice through the middle of the overlapping two layers of mural. Gently peel away the outer piece of excess material. Peel away the remaining excess material underneath the overlap. Smooth the panels back together and you should now have perfectly matched seams!

Watch our installation videos at  
[www.anewall.com/pages/installation](http://www.anewall.com/pages/installation)